Historic, Archive Document

Do not assume content reflects current scientific knowledge, policies, or practices.



Reserve aSB953 .F53 1981

METHODS APPLICATION GROUP 2810 Chiles Road, Davis, CA 95616

FIELD CREW INSTRUCTIONS FOR DEPOSIT CARD SAMPLING

INTRODUCTION

Spray deposit sampling is a vital part of any pilot project. Following a few simple procedures will insure that quality data are obtained.

The keys to producing quality spray deposit data are:

- (1) communication
- (2) organization
- (3) supervision

Past failures in obtaining quality spray deposit data have been caused in part by improper sampling design and positioning of spray cards, and poor handling of cards causing dirt spots, creases, smudges, dampness leading to warping, etc.

Experience has demonstrated the need for an area to organize and to stage sampling equipment. This staging area should be managed by the field-crew foreman and should be used to conduct crew briefings and issue the necessary equipment to each crew. Before each trial, the crews should meet at the

1000 m

ending the first to the free fitters

THE COST R FORM, DONES, A. 199-13.

See St. Commission of the second of the seco

-716.

The second contract of the second contract of

is sommer (1)

Tel 0: 300 "

ancervance (B)

greet to begin a considered and a second and

The second secon

equipment, drive to their assigned sampling area and place all their samplers in the proper positions before spray. After the spraying is completed and the crews have regathered their samplers, they should return to the staging area to organize and check the used deposit cards and to prepare their samplers for the next trial.

CREW PROCEDURES

- 1. Attend all field crew briefings and resolve any questions.
- 2. Check all your necessary equipment to insure everything is accounted for and in good condition. Necessary equipment:

Deposit cards including extras

Deposit card holders

Tote boxes for cards in holders

Storage sacks or boxes

Black felt-tip pens

Compass

Shovel or pulaski

Stakes or poles if required to elevate cards

Nails and flagging

Scrub brush, bucket, detergent, paper towels and drying rack for holders

3. Visit assigned sampling areas a day prior to the first trial and flag all sampler locations with a nail through the middle of a small strip (3-4 inches)

professor research nicht professor fan Art for in 1.1. minor in 1.1. minor professor for in 1.1. minor professor for in 1.1. minor professor for professor for in 1.1. minor professor sprojed statistics around in 1.1. minor professor sprojed sprojed

Physical Rev. May

Allend al! Field trow brightness and reserve the business

2s Obbis of your ne essent eminated and morning is a compression of the deed to deed the conditions. Nacestrans additions

Dapus i cords inclu ing corres

ent lanes langed

Told boxes for cardy in holders

Foger Backs on Done.

men grassing Apaff

na deminal

raeafun an found?

train process at forestant grand to someth

police and thisyling

the British success are upone, manner towerly may themper to the long

i yarat

of a possible seems seems and his colors took is about the seems of th

Con T

of flagging pushed in flush to the ground surface so the sampler can lay flat on top of it. The sampler locations will be at the four cardinal directions (N,E,S,W) under the sample tree drip-lines (see fig. 1 and 2 of attached diagram). If, in addition, a ground line(s) and/or drift line(s) of samplers is used on the project, follow instructions from your field-crew foreman concerning numbering and placement of these lines and flag in the manner described above.

- 4. Cards should be numbered before the trial with black felt-tip pen at the bottom edge of the card--please write your numerals carefully (see figs. 3 and 4 of attached diagram for numbering system). Place the card in the card holder (which together is referred to as a sampler) into the tote box in order with the bottom of the card up so the cards will not slip out of the holder and the numbers can be easily read.
- 5. Samplers should be placed in position the morning of the trial, <u>not</u> the night before, at the predetermined and flagged cardinal locations. Be sure that the sampler is not shielded by grass, branches, shrubs, rocks, etc., as such objects may intercept part of the spray droplets.
- 6. Start picking up the samplers no sooner than one hour (weather permitting) after the spraying is <u>completed</u> on your spray block. This will allow sufficient time for all spray droplets to settle and to dry on the card. Be sure not to touch the face of the card as this might smear the stains. As the samplers are picked up, check to be sure that the cards are properly numbered according to their location and that <u>none are missing</u>. Place the samplers in the tote box with the bottom of the card up as before. Be sure cards are kept

Assert and common and common as the following of the second of the secon

The first of the first of the first tells with block fells in participation of the constitution of the constitution.

control and the sheet trained and they coming of the 1944, at the control of the same of t

dry, and clean, and out of direct sunlight (sunlight causes fading of the dye and discoloration of the card).

- 7. Return to the staging area and remove the cards from the holders and place them in numerical order into their storage sacks or boxes as provided.
- 8. Deliver these cards to your field-crew foreman at the staging area or as otherwise instructed.
- 9. Wash all card holders in detergent to remove stains, dry thoroughly with paper towels and allow to stand in drying rack (preferably overnight) before the next trial.
- 10. Stage your equipment for the next trial.

eneffons; that que passible victor de l'aller passible de l'aller


The fig meaning order than a copy of

The definition of the state of

18. Râng, ou egyên, a cu til trans

1981 B.t. PILOT PROJECT FIELD CREW INSTRUCTIONS FOR DEPOSIT CARD SAMPLING **ILLUSTRATIONS** east Z Drip line -

Figure 1: Tree side view



-Sampler

Figure 2: Tree top view showing cardinal locations

Figure 3: Sampler

